

Integrated Access Controller



User Manual

Device Parameter

Communication:TCP/IP
 Communication Rate:10M/100M
 User Capacity: 20000
 Record Capacity:50000
 Alarm Record Capacity:20000
 Exit Button:1
 Door-Magnet:1

Authentication Mode: Password/Card(ID or IC)
 Reader Interface:1
 Input Protection:TVS lightning protection,PTC surge protection
 Output Protection:Varistor Protection
 Working Voltage:DC12V
 Working Current:Non-load<500mA
 Size(mm):A L122 ×W77 ×H39
 B L108 ×W77 ×H26
 C L122 ×W77 ×H36

Advanced Features

For advanced features, please use Business software.



Staff Attendance

Time attendance management can realize working hours setting, shift overtime register, leave register, add missed card record, attendance count and other functions.



Information Query

Access records, alarm records, attendance details and other information queries.



Multiple identification modes are used in combination


RFID, password are all used.

Professional Features

For professional features, please adopt the Plus software.

| | |
|-----------------------------|---|
| First-card | Any card can be first-card |
| Multi-card | Support 4 cards |
| Remote Access Control | Any door can be opened via center authentication |
| Enforced control | Forced open/close door for long time |
| Threaten Code | A group of 6 digits code |
| Open Door by Password | Every user can be assigned with one password |
| Door Normal Open Timed | Normal open can be set for three time segments |
| Door Bolt Mode | Normal open in unfixed time |
| Anti-passback | Two readers or all readers can be set in a group |
| Limit Valid Date | To set user valid date, user will limit to access after valid date, it can be accurate to the hour. |
| Global Anti-passback | User can set all devices that managed by software as global anti-passback group by software. |
| Self-defined Input / Output | Self-defined input/output and relay |
| Activate/Dismiss Security | Any user can activate/dismiss security by card/fingerprint or software |
| Data Storage Mode | Cycled Storage |
| Video Record/Snapshot | Related video, record or snapshot via software |
| Access Authority | 200 groups |
| Authentication Mode | Card/Password |
| Reader Protocol | Wiegand26/34 |
| Real-time Monitor | Software can real-time monitor the status of access and alarm. |
| Alarm Linkage | Valid fingerprint, invalid fingerprint and alarm input can trigger the specified relay action. |

Product Appearance



Tamper button and Clear Communication Password:
To press the tamper button 5 times to clear the communication password. After clearing, it will beep.

Indicator Light and Sound Indication

Take A as an example:



Red light indicates that the device is working properly.



One sound means that can access



The green light indicates that can access.



Three sounds indicate that no access.



Blue light indicates device is programming status. Continuous blinking indicates entering the programming status.







The continuous long beep indicates that the device has been removed.

Disclaimer

The document provides information according to products specification. My company does not undertake any type of guarantee, express or implied warranties, including any implied merchantability, specific purposes or the infringement. The information in the document are changed without prior notice.


My company and its associated sales agents special statement does not assume the result of the use of My company equipment of any and all direct, indirect, special, in general, by chance, inevitably, punitive damages. Any user's improper operation or use of the environment problem caused by direct or indirect losses, user pays full responsibility, equipment manufacturers and related sales agents does not undertake any responsibility.

Product Installation




① Put the positioning paper on the wall, follow the icon to punch and pass the cable out.

② Fix back cover with self-tapping screws, place the device into the middle frame, then connect device by the cable.




B




③ Align the bayonet of the front cover to the bottom cover gap, buckle downward.

④ Rotate the bottom of the front cover inward, until fully buttoned into the bottom cover.



⑤ Tighten the screw from the bottom to make the front cover fixed with the bottom cover.



⑥ Take the body height of 170cm as an example, the recommended installation height is 130 cm.

Important Notices




If user do not follow below items, system may not work well, even bring some damages.

1. Any connection and operation are prohibited when components or the controller is power on.
2. Please connect the system according to the instructions described in this manual.
3. IP address should not be repeated. If there are two network cards in PC, please prohibit one.
4. Please use specified power supply.

Wiring Diagram

Take B as an example:




Business software is easy to manage employee access at the office site, also anti-theft, employee attendance and care for staff.

Communication

Software

- Time Attendance
- Office Safety
- Staff Access
- Devices Mangement



TX+

TX-

RX+


RX-




Device

Wiring Diagram


Reader



Lock






Exit Button, Door-Magnet and Alarm Input



Wiring Diagram

Alarm Output



Instruction for keypad operation

This operation applies to A/B/C.

1. Operation Indication

1.1 Sound Indication:

1.1.1 One long sound is operation successful or enter menu.

1.1.2 Three short sounds is operation failure. The position is registered/Reader is registered.

1.2 LED Light Indication:

Red: Power indication light, after power on, the light on.

Bule: Enter program mode.

Green: It is success to input program command and executive command.

2. Setup Operation

1) Enter Edit Mode

Press "*" and input administrator password (Default is 000000).

If password correct then enter edit mode, or return to main interface.

2) Basic Setup

Basic Setup: System initialization, dismiss/activate security, tamper setup, exit button setup, door-magnet setup, alarm setup.

2.1 System Initialize

System initialize will clear device all setups, register information and records to original.

Operation: Edit Mode—>Input 11 Initialize

When successful, a long buzzing and return to upper menu.

2.2 Dismiss/Activate Security

Operation: Edit—>Input 121 enter Activate Security.

 Edit—>Input 122 enter Dismiss Security

2.3 Tamper Setup:

Operation: Edit—>13 Enter Tamper Setup

 Input 00 Cancel Tamper

 Input 01 Start Tamper

2.4 Exit Button Setup

Exit button setup: Exit button Type , Exit button disabled

2.4.1 Exit Button Type

Operation: Edit—>Input 141 Enter Exit Button Type Setup

 Input 01 enter Normal Open

 Input 00 enter Normal Close

2.4.2 Exit Button Disabled Setup

Operation: Edit—>Input 142 Enter Setup

 Input 01 enter Exit button valid

Instruction for keypad operation

Input 00 enter Exit Button Disabled

2.5 Door-Magnet Setup

Door-Magnet Setup: Door-Magnet Type Setup, Door-open time-out length setup

2.5.1 Door-Magnet Type Setup

Operation: Edit—>Input 151 Enter Setup

Input 01 enter Normal Open

Input 00 enter Normal Close

2.5.2 Door-open Time-out Length Setup

Operation: Edit—>Input 152 Enter Setup

Input two number (00 to 99), unit: second

2.6 Alarm Setup

Alarm Setup: Alarm Type Setup, Alarm Action Delay, Alarm Relay Output.

2.6.1 Alarm Type Setup

Operation: Edit—>Input 161 Enter Setup

Input 01 enter Normal Open

Input 00 enter Normal Close

2.6.2 Alarm Action Delay Setup

Operation: Edit—>Input 162 Enter Setup

Input two number (00 to 99), unit: second

2.6.3 Alarm Relay Output Setup

Operation: Edit—>Input 163 Enter Setup

Input 1 Relay 1 output

Input 2 Relay 2 output

Input 3 Relay 1 and 2 output

Input 4 Not Output

3) Access Mode Setup

Access Mode Setup: Door-open Delay, Door-open Mode

3.1 Door-Open Delay

Operation: Edit—>Input 21 Enter Setup

Input two number (00 to 99), unit: second

3.2 Door-open Mode Setup

Operation: Edit—>Input 221 Open by Card

Input 222 Card+Password

Input 223 Password

Input 224 Card or Password

4) Staff Management

Staff Management: Add Card, Delete Card

Instruction for keypad operation

4.1 Add Card

Add Card: Add card continuously, add single card, add card+password continuously, add single card+password, add single password, add password continuously.

4.1.1 Add Card Continuously

Operation: Edit—>Input 31—>Input 4-digit initial code—>Read Card continuously—>Press"#" exit

4.1.2 Add Single Card

Operation: Edit—>Input 32—>Input 4-digit code—>Read Card—>Press"#" exit

4.1.3 Add Card+Password Continuously

Operation: Edit—>Input 33—>Input 4-digit initial code—>Read Card—>Input Password—>Re-input Password—>... —>Press"#" exit

4.1.4 Add Single Card+Password

Operation: Edit—>Input 34—>Input 4-digit code—>read Card—>Input Password—>Re-input Password—>Press"#" exit

4.1.5 Add Password Continuously

Operation: Edit—>Input 35—>Input 4-digit initial code—>Input Password—>Re-input Password—>... —>Press"#" exit

4.1.6 Add Single Password

Operation: Edit—>Input 36—>Input 4-digit code—>Input Password—>Re-input Password—>Press"#" exit

4.2 Delete Card

4.2.1 Delete card by 4-digit code or read the card

Operation: Edit—>Input 37—>Input 4-digit code or read card—>Automatically exit

4.2.2 Delete All Cards

Operation: Edit—>Input 38—>Delete All Cards—>Automatically exit

Operation: Edit—>Input 38—>Delete All Cards—>Automatically exit

5) Password Management

Password Management: Admin Password, Threaten code

5.1 Admin Password Setup

Operation: Edit—>Input 41—>Input new password—>Re-input new password—>Automatically Exit


5.2 Threaten code Setup

Operation: Edit—>Input 42—>Input new code—>Re-input new code—>Automatically Exit

Software Description



Software Icon



User Name:administrator

The default login password is empty

Login Software

HOME

Home
User can quickly add devices, staff, fingerprint, face and other identity information according to the steps, and finally synchronize the data to the devices.



Click here to enter the setting interface


In the home page, user can switch to different setting interface. Just 4 steps to complete settings.

Enter Home page

Record query, attendance management, modify login password at here.

Information Query

Attendance Management



Access records, alarm records, attendance details and other information queries, and export an Excel file.



Time attendance management can realize working hours setting, shift, overtime register, leave register, add missed card record, attendance count and other functions

① Click add Device to enter the searching interface.

| No.: | Name: | Model: | IP Address: | MAC Address: | Port: | Operation |
|------|------------------------|--------|-------------|-------------------|-------|--------------------------|
| 1 | 10.1.0.81_00D1EFDF2081 | DF20 | 10.1.0.81 | 00 D1 EF DF 20 81 | 50000 | [Add] [Refresh] [Delete] |
| 2 | 10.1.0.82_00D1EFDF2082 | DF20 | 10.1.0.82 | 00 D1 EF DF 20 82 | 50000 | [Add] [Refresh] [Delete] |
| 3 | DF40 | DF40 | 10.1.0.84 | 00 D1 EF DF 40 84 | 50000 | [Add] [Refresh] [Delete] |
| 4 | 10.1.0.83_00D1EFDF2083 | DF20 | 10.1.0.83 | 00 D1 EF DF 20 83 | 50000 | [Add] [Refresh] [Delete] |

| No.: | Name: | Model: | IP Address: | MAC Address: | Port: | Version No.: | Operation |
|------|-----------------------|--------|-------------|-------------------|-------|--------------|--------------------------|
| 1 | 10.1.0.81_00D1EFDF... | DF20 | 10.1.0.81 | 00 D1 EF DF 20 81 | 50000 | 3.7 | [Add] [Refresh] [Delete] |
| 2 | 10.1.0.82_00D1EFDF... | DF20 | 10.1.0.82 | 00 D1 EF DF 20 82 | 50000 | 3.7 | [Add] [Refresh] [Delete] |
| 3 | 10.1.0.83_00D1EFDF... | DF20 | 10.1.0.83 | 00 D1 EF DF 20 83 | 50000 | 3.7 | [Add] [Refresh] [Delete] |
| 4 | DF40 | DF40 | 10.1.0.84 | 00 D1 EF DF 40 84 | 50000 | 3.7 | [Add] [Refresh] [Delete] |
| 5 | DF40 | DF40 | 10.1.0.85 | 00 D1 EF DF 40 85 | 50000 | 3.7 | [Add] [Refresh] [Delete] |
| 6 | DF40 | DF40 | 10.1.0.86 | 00 D1 EF DF 40 86 | 50000 | 3.7 | [Add] [Refresh] [Delete] |

| Device Communication Setup | |
|----------------------------|-----------|
| IP Address | 10.1.0.81 |
| Subnet Mask | 255.0.0.0 |
| Port | 50000 |
| Default Gateway | 10.0.0.1 |

Click here to add device

Device List

② Add device

③ Click here to modify IP address, gateway, subnet mask

1. Add Device

Next Page

Software Description

2. Staff Management

① Add Staff

Click here to enter Staff Management interface

Basic Information

Authentication Information

Password, card, fingerprint, face

Modify fingerprint collection device. The current device is...

② Set staff information and save.

③ Register fingerprint information.

③ Register face information.

Modify face collection device. The current device is...

3. Staff Settings

After set Holiday, no access in holidays except administrator, and door normal open mode setup is invalid

① Select the door to set

Click here to enter Access Granted interface

Set access time

③ Select staff who can access

② Click it to enter staff list and select staff to access the door.

4. Sync Settings

① Click here to synchronize software settings to device

② Setting is done, start to use

Click here to enter the sync settings interface

Software Description

Terms Explanation

Administrator: There is Staff Type in staff attributes. Administrators can access any door within 24 hours. He is no need to set it in the access granted. Staff: It is need to specify which door they can access in the access granted, the door access time and holiday schedule. Access is available during the specified time and non-holiday.

Latch Mode: When using the bolt mode, it means that door can open or close by valid card (granted), and the door does not switch the state automatically. For example, if the door is open now, swiping the valid card will close the door; if the door is closed now, swiping the valid card will open the door; if the card is not swiped, the door will not close or open automatically.

Keep Opening After Valid Access: In order to keep the door in the normally open state for a certain period, and does not trigger the door magnetic alarm, we need to set a door opening weekly schedule to specify the time for the door keeps open, but during the time, the door will be not opened automatically. Door will return normal open after a valid door opening action is triggered. The door will close automatically after the end of the period.

Normal Open Automatically: The normal open automatically mode is same as Keep Opening After Valid Access, and the door will open normally during the period specified in week schedule, but the difference is that the Normal Open Automatically does not need a valid door opening triggering. When the set time arrival, the door will be opened automatically and keep open.

System Holiday Setting

Click here to set

| Address | Week Schedule | Holiday Schedule |
|------------|---------------|------------------|
| F DF 20 81 | Enabled | |
| F DF 20 82 | | |
| F DF 40 84 | | |
| F DF 20 83 | | |
| F DF 40 85 | | |

The setting of the holiday will affect the access time of the staff and door normal open time. In the holiday, no access except administrator. In the holiday, even if the door normal open is set, the door will not open normally.

Other Settings

Door Access Setting

Access Granted

Click here to set

| Week | Starting Time1 | End Time1 | Starting Time2 | End Time2 | Starting Time3 | End Time3 |
|-----------|----------------|-----------|----------------|-----------|----------------|-----------|
| Sunday | 00:00 | 00:00 | 00:00 | 00:00 | 00:00 | 00:00 |
| Monday | 00:00 | 23:59 | 00:00 | 00:00 | 00:00 | 00:00 |
| Tuesday | 00:00 | 23:59 | 00:00 | 00:00 | 00:00 | 00:00 |
| Wednesday | 00:00 | 23:59 | 00:00 | 00:00 | 00:00 | 00:00 |
| Thursday | 00:00 | 23:59 | 00:00 | 00:00 | 00:00 | 00:00 |
| Friday | 00:00 | 23:59 | 00:00 | 00:00 | 00:00 | 00:00 |
| Saturday | 00:00 | 00:00 | 00:00 | 00:00 | 00:00 | 00:00 |

The setting of the access time will affect the access time of the staff and door normal open time. Each door is set to a different access time, and only the administrator can access during the non-access time. The door will open normally during the access time. There are three modes for door normal open.